

LUX Downlight DL50 Installation Guide

Full spectrum color tuneable lighting, including cold and warm white light

Please read the following pages before attempting installation




Before you start...


- Always ensure that the vessel's power source and battery are disconnected or isolated prior to installation.
- A qualified professional should carry out both the electrical and mechanical installation.
- The Lux Downlight Is designed to be used in conjunction with the Lumishore Lux
 Downlight module (see diagram below). Do not connect to any other 3rd party lighting
 control products or dimmers.
- The lux downlight is fully sealed and can be installed inside or outside, it can be installed in wet areas but is not designed to be permanently submerged in water.
- Choose a location the light must be mounted on a flat not curved surface.
- The rear of the light may get warm to touch, it will not cause damage to the mounting surface.



Basic Dimensions:



Installation Diagram



NOTE: The Lumishore Lux downlight DL50 requires connection to the Lumishore Lux Downlight Module. For full electrical installation and wiring diagrams please refer to the Lux Downlight Module installation guide.


Power rating = 4.5watts per light


Typical current draw = 0.37A @ 12Volt / 0.18A @24Volt




Mechanical Installation:


Using a hole saw cut a 2in hole, always cut the hole smaller than needed and file to the correct size to ensure a snug fit. For indoor installations use the supplied spring clips, gently pull back the spring clips and feed the light into the hole, releasing the spring clips as the light is positioned.





For exterior installations or wet areas it is recommended that the light is fixed in place using a suitable marine sealant / adhesive. *Remove the spring clips* from the fixture and dispense a small amount of adhesive around the glass bezel. Push into place using a slight rotation of the light to spread the adhesive evenly. Clean any excess adhesive using a soft cloth and soap and water – *DO NOT USE CHEMICAL CLEANERS*.







Warranty

LUMISHORE Ltd warrants the **LUX Downlight DL50** to be free from defects in workmanship and materials for a period of two years, starting from the date of original purchase. Misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, installation by unqualified personnel, unauthorized repair or modification will void this warranty. For the avoidance of confusion and doubt, non-compliance with all installation, maintenance and operating instructions in this document constitute non-conformance with warranty terms.

The LUX Downlight Control Module is designed to work with Lumishore LUX strip lighting products ONLY, do not use with other Strip light brands, this will invalidate the warranty.

